


Whirlpool Operating Instructions



Pump

Press PUMP 1:

- 1st press → Low speed
- 2nd press → High speed
- 3rd press → Off

The LED lights up when the pump is on.

The pump automatically turns off after 20 minutes.

Temperature

Use the UP / DOWN buttons to set the desired temperature (recommended: 35–36°C).

The “SET POINT” icon shows the selected temperature, not the current water temperature.

Light

Press LIGHT to turn the light on/off.

The light automatically turns off after 2 hours.

Pompa

Premere POMPA 1:

- 1ª pressione → Velocità bassa
- 2ª pressione → Velocità alta
- 3ª pressione → Spento

Il LED si accende quando la pompa è attiva.

La pompa si spegne automaticamente dopo 20 minuti.

Temperatura

Usare i pulsanti SU / GIÙ per impostare la temperatura desiderata

(consigliata: 35–36°C).

L'icona “SET POINT” indica la temperatura impostata, non la temperatura attuale dell'acqua.

Luce

Premere LUCE per accendere o spegnere la luce.

La luce si spegne automaticamente dopo 2 ore.